



Nilfisk




128337311

Kornmarksvej 1|DK-2605 Broendby|Denmark|Tel.: (+45) 4323 8100

Quick Start Guide - Excellent 180

Caution: Read the instructions before using the machine




Excellent 180


A




1




2



3




4




A




5




6



7




8




A






9



10




11




A




12



13






13.2




A




14



15




16




B




1




2



3




4




B




5




6



7




8




B



9




10




11


11.1



11.2



11.3





B




12


12.1




12.2







12.3




C




1




2



3




C




4


4.1



4.2



5




MAX 2min




6


6.1




6.2




6.3



6.4



7




D

⏸ >5min




1




2


2.1



2.2




2.3



E



1



1.1



1.2




F




1


1.1




1.2



2



3



FR
Cet appareil
se recycle

À DÉPOSER
EN MAGASIN

À DÉPOSER
EN DÉCHÈTERIE



OU



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !